



# Installation and Troubleshooting Guide



NOTE: This installation is to be completed by an Authorized Dealer or Professional Service Technician. For questions regarding installation or warranty, call CDI Tech Support at 866-423-4832. **Do not return to the Dealer or Distributor where the part was purchased. Contact CDI Electronics Directly for Return Material Authorization.**

## CDI P/N 413-9910 Wiring Harness 4 Cyl.

This harness will replace P/N: 382777. Fits 1968 85 HP Johnson/Evinrude engines with Electric Shift.


**WARNING! This product is designed to be installed by a professional marine mechanic. CDI Electronics cannot be held liable for injury or damage resulting from improper installation, abuse, neglect or misuse of this product.**

### INSTALLATION

1. Disconnect battery.
2. Remove original wiring harness. Be sure to make note of wire routing.
3. With old wiring harness removed clean all connection points to verify good connection of new wiring harness.
4. Install new wiring harness in the same position as original wiring harness.
5. Connect the new wire harness to the boat side harness (SERVICE NOTE: Remove the locator tab on the new harness connector in order to connect it to the boat side harness. The original connector with the locator pin to one side has not been available for over 20 years).
6. Verify proper placement of all wires. Reconnect battery.
7. Wire color chart.
  - 1) **Red (2)** – Connects to the Choke, Thermo Switch and the Power Pack (Amplifier).
  - 2) **White**- Switched power to starter solenoid and Neutral Safety Switch.
  - 3) **Black**- Engine Ground wire.
  - 4) No Connection.
  - 5) **Grey**- Connects with one of the Yellow wires going to the rectifier (Tach Signal).
  - 6) No Connection.
  - 7) No Connection.
  - 8) **Red/White**- Connects to the Choke.
  - 9) **Tan** - Connects to the Temperature Sensor located on the cylinder head (may be a Brown/Yellow wire).
  - 10) **Green (2)**- Battery cable side of the starter solenoid and the Rectifier.

SERVICE NOTE: A Purple/Yellow jumper wire is used in place of the Red/Yellow jumper wire in the original wire harness. This jumper connects the Thermo Switch with the electric Choke.

NOTE: This installation is to be completed by an Authorized Dealer or Professional Service Technician. For questions regarding installation or warranty, call CDI Tech Support at 866-423-4832. **Do not return to the Dealer or Distributor where the part was purchased. Contact CDI Electronics Directly for Return Material Authorization.**



CDI Electronics, LLC • 353 James Record Road SW • Huntsville, AL 35824 USA  
 Web Support: [www.cdielelectronics.com](http://www.cdielelectronics.com) • Tech Support: 1-866-423-4832 • Order Parts: 1-800-467-3371  
 All rights reserved. Reproduction or use of content, in any manner, without express written permission by CDI Electronics, LLC., is prohibited.